

# 1800 Series Water Meter Instructions

## Sizes: 1/2" to 12"

1. Before beginning the installation, verify that the system temperature, pressure and flow rate do not exceed the ratings indicated on the meter.
2. The meter is designed to operate at a sustained flow of 1/2 the Maximum Flow Rating (indicated as the Continuous Flow Rating). The meter should not be operated at the Maximum Flow Rating for more than one hour per day as excessive wear and/or failure will result.
3. Flush the pipeline thoroughly after any plumbing changes to eliminate the possibility of foreign materials reaching the meter.
4. The 1/2" and 3/4" meters may be installed in horizontal or vertical pipelines (either up or down flow). To achieve the rated accuracy, the meter should be the same diameter as the pipe and there should be at least five (5) pipe diameters of straight pipe before and after the meter. The 1" through 2" meters have a specific flow orientation and must be installed accordingly. There is no straight pipe requirement before or after the 1" through 2" (1820 only) meters. The 2" (1825 only) and larger meters may be installed horizontally or vertically and require at least five (5) pipe diameters of straight pipe before and after the meter. In horizontal installations, the flow counter should be facing straight upward.
5. Pay careful attention to the flow direction as indicated by the arrow cast into the meter body.
6. It is highly recommended that a strainer be installed upstream of the meter inlet. It is also recommended that a shutoff valve be located before and after the meter to facilitate service.
7. Care should be taken to protect the meter from water hammer as well as freezing temperatures.
8. The counter is calibrated in U.S. gallons and cannot be reset. It will roll around to zero after reaching its maximum reading.
9. Meters with a pulse output contain a magnetically driven "dry contact type" reed switch. Each contact closure is equal to one (1) or ten (10) gallons of water as indicated on the meter. The electrical rating of the switch is 0.2 amp at 24 volt.

For Sales & Service Contact:


41 Magnolia Avenue  
Cambridge MA 02138  
Phone: (617) 290-2134  
Fax: (240) 250-8907

**Follin Flo-Controls**  
[www.FollinFlo-Controls.com](http://www.FollinFlo-Controls.com)  
[sales@FollinFlo-Controls.com](mailto:sales@FollinFlo-Controls.com)

Doc. Ref: 1800\_water\_inst\_FFC\_v1

5 Heritage Hill Rd.  
Norwalk, CT 06851  
Phone: (203) 845-0593  
Fax: (203) 846-3825

### Reading 1800 Series Water Meters



The 1800 Series counter consists of a row of numbers (roller counter) and one or more circular dials with rotating pointers. There is also a star shaped wheel that rotates whenever flow is present (trickle indicator).

The roller counter is calibrated in U.S. gallons and cannot be reset. It indicates the total flow through the meter in gallons, hundreds of gallons or thousands of gallons. The correct multiplier is indicated on the face adjacent to the roller counter. In the example above, the total indicated is 345 x 100 or 34,500.

The circular dials indicate tenths of gallons, gallons and tens of gallons. The respective multiplier is marked adjacent to the dial. For example, on the dial marked "x10", each number represents increments of ten gallons (i.e. 3 = 30 gallons, etc.) and one full rotation equals 100 gallons. On the dial marked "x0.1", each increment is one tenth (1/10) of a gallon (4 = 0.4) and a full rotation of the dial represents a total of 1 gallon. Note that if the pointer is between two numbers, the lower number is read.

The counter will roll around to zero and restart once it reaches its maximum reading.